

The logo for Link tech, featuring the word "Link" in a large, white, sans-serif font with "tech" in a smaller font below it.The logo for Trend Product, featuring a stylized "TP" symbol above the words "TREND" and "PRODUCT" in a bold, sans-serif font.

LPH-TW10
TRUE WIRELESS EARBUDS
User Manual

Hello!

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Link Tech User,

Thank you for choosing Link Tech product. Your choice is crucial for us, which means Link Tech has added a new user. Hope that we will bring you a good experience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Whatsapp and Bp in the process of product experience, which can help Link Tech to constantly improve product and service.

If you encounter any problems in using this product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to Link Tech. Thank you!

Link Tech Sales Team

TRUE WIRELESS EARBUDS



Features

- Bluetooth version 5.1+EDR
- Voice assistant compatible(Google & Siri)
- Touch Control-Music Track, Volume +/-, Calls & Voice assistant
- Type-C
- Splash & Sweat Resistant
- Pocket Friendly & Light Weight Case
- 5 Hours Playback with Single charge
- 15 Hours Playback with the case
- Hi-Quality microphone
- 13mm Dynamic Drivers

Specifications

Bluetooth Version	V5.1 + EDR
Bluetooth Frequency	2.4GHZ
Bluetooth Range	10m
Earbuds Battery	25mAh
Charging Case Battery	300mAh
Charging Time	1.5H
Support	HSP , HFP , A2DP , AVRCP

Package contents

This package contains the items listed below.



Earphones



Charging Case



User Manual



USB-C
Charging Cable

Multi-Function Button (MFB)

Earbud Charging Point

Type-C Charging Point



OPERATING YOUR EARBUDS

Before First Use



In order to have a very good experience, pls charge the charging case and earbuds before you use them.



• Charging LED

When you charge the case, the case LED flashes RED.

When the case is fully charged, the RED LED remains ON.

• Bluetooth pairing

To facilitate a better user experience, pairing between left and right earbuds is done automatically.

• Pairing between the earbuds and mobile device:

Take out the earbuds from the charging case, the main earbud will enter into pairing mode automatically, please enable the Bluetooth function on your device to search, pair and connect to the Link-TW10

• Going to Previous Song

Long press MFB in Left earbud



• Going to Next Song

Long press MFB in Right earbud



• Volume Up & Down

1 time touching MFB on Right earbud to increase.

1 time touching MFB on Left earbud to decrease the volume



Press 1 Time

Volume Down

Volume Up

• Refuse call

Long press MFB on either of the earbud



Long press

• Pause & Play Song

Double touch on MFB on either of the earbud to Pause & Play the song



• Receiving Call

Single touch on either of the earbud to receive a call



• End call

Double Press either of the earbud on MFB to end the calls



• Using Google Voice Assistance/Siri

Triple-click MFB on the either of the earbud and the Google Voice Assistance/Siri will be activated



Triple-click

Note: Control functions may vary as per the device connected.

SAFETY INSTRUCTIONS

Precautions

- Before using the product check for any damage. If there is any damage or if you observe any unpleasant smell, do not use the product.
- The product should be stored in a dry and ventilated environment, to avoid oil, water, moisture and dust affecting product performance.
- Avoid using stimulus, organic solvents or items containing these ingredients to clean the Earbuds.
- The use of Earbuds should be correct as per the specification, pay attention to use the influence of the environment on the Earbuds.
- In order to ensure an uninterrupted connection, it is recommended that the distance between the Earbuds and phone is within 10-15 meters.
- It is advisable to unplug the product from the power source once charged fully & if the unit is not to be used for a long time.
- Do not use any accessory which is not compatible with the product, as it may result in a malfunction of the product; which will also void the warranty.
- Do not attempt to service/repair the product on your own, as this may expose you to potential electric shock and hazards, resulting in electrocution. This will also void the warranty claim.

Link
tech

TREND
PRODUCT

LPH-TW10

Bluetooth Kulaklık

KULLANIM KILAVUZU

Merhaba!

Bu ürünü kullanmaya başlamadan önce lütfen kullanım kılavuzunu dikkatlice okuyun ve saklayın.

Sayın Linktech Kullanıcısı,

Linktech ürününü tercih ettiğiniz için teşekkür ederiz. Seçiminiz bizim için çok önemlidir. Ürünlerimiz ve hizmetlerimiz aracılığıyla size iyi bir deneyim sunacağımızı umuyoruz. Ayrıca, ürün deneyimi sürecinde Linktech'in ürün ve hizmeti sürekli iyileştirmesine yardımcı olabilecek resmi müşteri hizmetleri aracılığıyla tavsiye ve öneriler sunacağınızı umuyoruz.

Ürünü kullanırken herhangi bir sorunla karşılaşırsanız, lütfen servis hizmetine başvurun. Satış sonrası desteğimiz bizim en güçlü avantajımızdır. Teşekkür ederiz!

Bluetooth Kulaklık



Özellikler

- Bluetooth Sürüm 5.1+EDR
- Sesli Asistan Uyumlu (Google ve Siri)
- Dokunmatik Kontrol - Müzik Kontrol, Ses +/-, Çağrılar ve Ses Yardımcısı
- Tip-C
- Sıçramaya ve Tere Dayanıklı
- Cep Dostu ve Hafif Çanta
- Tek Şarjla 5 Saat Oynatma
- Kasayla birlikte 15 Saat Oynatma
- Yüksek Kaliteli Mikrofon
- 13 mm Dinamik Sürücüler

Teknik Özellikler

Bluetooth Sürümü	V5.1 + EDR
Bluetooth Frekansı	2.4GHZ
Bluetooth Menzili	10m
Kulakçı Pili	25mAh
Şarj Kutusu Pili	300mAh
Şarj Süresi	1.5 Saat
Destek	HSP , HFP , A2DP , AVRCP

Paket İÇeriĐi

Bu paket, aŐaĐıda listelenen öğeleri iĐerir.



Kulaklık (çift)



Őarj kutusu



Kullanım kılavuzu



USB-C Őarj kablosu

Çok İŐlevli DűĐme (MFB)

Kulaklık Őarj Noktası

Type-C Őarj Noktası



Kulaklık Eşleştirme

İlk Kullanımdan Önce



İyi bir deneyim yaşamak için lütfen kullanmadan önce şarj kutusunu ve kulak içi kulaklıklar şarj edin.



• Şarj Göstergesi

Kasayı şarj ettiğinizde LED kırmızı yanıp söner.

Kasa tamamen şarj olduğunda kırmızı LED sürekli açık kalır.

• Bluetooth eşleştirme

Daha iyi bir kullanıcı deneyimi sağlamak için sol ve sağ kulaklıklar arasında eşleştirme otomatik olarak yapılır.

• Kulaklıklar ve mobil cihaz arasında eşleştirme:

kulak içi kulaklıklar şarj kutusundan çıkarın, ana kulaklık otomatik olarak eşleştirme moduna girecektir, lütfen Link-TW10'u aramak, eşleştirmek ve bağlanmak için cihazınızdaki Bluetooth işlevini etkinleştirin.

• Önceki Şarkıya Gitmek

Sol kulaklıkta MFB'ye uzun basın.



• Sonraki Şarkıya Gitmek

Sağ kulaklıkta MFB'ye uzun basın.



• Sesi Açma ve Azaltma

Arttırmak için Sağ kulaklıktaki

MFB'ye 1 kez dokun.

Sesi azaltmak için Sol kulaklıkta

MFB'ye 1 kez dokun.



1 Kez Basın

Sesi kıs

Sesi aç

• Aramayı reddet

Kulaklıklardan herhangi birinde

MFB'ye uzun basın.



uzun basın

• Şarkıyı Duraklat ve Çal

Şarkıyı Duraklatmak ve Çalmak için

kulaklıklardan herhangi birinde

MFB'ye iki kez dokun.



• Çağrı Alma

Bir çağrı almak için kulaklıklardan birine tek dokunuş gerçekleştirin.



• Son Arama

Aramaları sonlandırmak için MFB'deki kulaklıklardan birine iki kez basın.



• Google Voice Assistance/Siri'yi kullanma

Kulaklıklardan birine MFB'ye üç kez tıkladığınızda Google Voice Assistance/Siri etkinleştirilir.



3 Kez Basın

Not: Kontrol işlevleri, bağlanan cihaza göre değişiklik gösterebilir.

GÜVENLİK TALİMATLARI

Önlemler

- Ürünü kullanmadan önce herhangi bir hasar olup olmadığını kontrol edin. Herhangi bir hasar varsa veya hoş olmayan bir koku görürseniz ürünü kullanmayınız.
- Ürün performansını etkileyen yağ, su, nem ve tozdan kaçınmak için ürün kuru ve havalandırılmış bir ortamda saklanmalıdır.
- Kulaklıkları temizlemek için uyarcı, organik çözücüler veya bu bileşenleri içeren maddeler kullanmaktan kaçının.
- Kulakiçi Kulaklıkların kullanımı teknik özelliklere göre doğru olmalıdır, Kulakiçi Kulaklıklar üzerinde çevrenin etkisinin kullanılmasına dikkat edin.
- Kesintisiz bağlantının sağlanabilmesi için Kulaklık ile telefon arasındaki mesafenin 10-15 metre arasında olması tavsiye edilir.
- Tam olarak şarj edildikten sonra ve ünite uzun süre kullanılmayacaksa, ürünü güç kaynağından çıkarmanız tavsiye edilir.
- Ürünle uyumlu olmayan herhangi bir aksesuar kullanmayınız, aksi takdirde üründe arızaya neden olabilir; bu da garantiyi geçersiz kılacaktır.
- Potansiyel elektrik çarpması ve tehlikelere maruz kalabileceğiniz ve elektrik çarpmasıyla sonuçlanabileceğinden, ürüne kendi başınıza servis/onarım yapmaya çalışmayın. Bu aynı zamanda garanti talebini de geçersiz kılacaktır.