

# LPH-TW10 TRUE WIRELESS EARBUDS User Manual

Hello!

Dear Link Tech User.

Thank you for choosing Link Tech product. Your choice is crucial for us, which means Link Tech has added a new user. Hope that we will bring you a good expeience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Whatsapp and Bip in the process of product experience, which can help Link Tech to constantly improve product and service.

If you encounter any problems in using this product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to Link

Tech. Thank you!

Link Tech Sales Team

.

## TRUE WIRELESS EARBUDS



#### **Features**

- Bluetooth version 5.1+EDR
- Voice assistant compatible(Google & Siri)
- Touch Control-Music Track, Volume +/-, Calls & Voice assistant
- Type-C
  - · Splash & Sweat Resistant
  - · Pocket Friendly & Light Weight Case
  - 5 Hours Playback with Single charge
  - 15 Hours Playback with the case
  - Hi-Quality microphone
  - 13mm Dynamic Drivers

#### **Specifications**

Bluetooth Version	V5.1 + EDR	
Bluetooth Frequency	2.4GHZ	
Bluetooth Range	10m	
Earbuds Battery	25mAh	
Charging Case Battery	300mAh	
Charging Time	1.5H	
	HSP . HEP . A2DP . AVRCP	

#### Package contents

This package contains the items listed below.



Earphones





User Manual



USB-C Charging Cable

Multi-Function Button (MFB)

Earbud Charging Point

Type-C Charging Point

#### **OPERATING YOUR EARBUDS**

Refore First Use



In order to have a very good experience, pls charge the charging case and earbuds before you use them.



## Charging LED

When you charge the case, the case LED flashes RED.

When the case is fully charged, the RED LED remains ON.

#### Bluetooth pairing

To facilitate a better user experience, pairing between left and right earluds is done automatically.

#### Pairing between the earbuds and mobile device:

Take out the earbuds from the charging case, the main earbud will enter into pairing mode automatically, please enable the Bluetooth function on your device to search, pair and connect to the Link-TW10

#### • Going to Previous Song

Long press MFB in Left earbud



#### Going to Next Song

Long press MFB in Right earbud



# Volume Up & Down I time touching MFB on Right earbud to

- increase.
- 1 time touching MFB on Left earbud to decrease the volume



Volume Down

Volume Un

#### Refuse call

Long press MFB on either of the earbud



Long press

#### Pause & Play Song

Double touch on MFB on either of the earbud to Pause & Play the song



#### • Receiving Call

Single touch on either of the earbud to receive a call



#### End call

Double Press either of the earbud on MFB to end the calls



# Using Google Voice Assistance/Siri Triple-click MFB on the either of the

earbud and the Google Voice Assistance/Siri will be activated



Note: Control functions may vary as per the device connected.

#### SAFETY INSTRUCTIONS

#### Precautions

- Before using the product check for any damage. If there is any damage or if you observe any unpleasant smell, do not use the product.
- The product should be stored in a dry and ventilated environment, to avoid oil, water, moisture and dust affecting product performance.
- Avoid using stimulus, organic solvents or items containing these ingredients to clean the Earbuds.
- The use of Earbuds should be correct as per the specification, pay attention to use the influence of the environment on the Earbuds.
- In order to ensure an uninterrupted connection, it is recommended that the distance between the Earbuds and phone is within 10-15 meters.
- It is advisable to unplug the product from the power source once charged fully & if the unit is not to be used for a long time.
  - Do not use any accessory which is not compatible with the product, as it may result in a malfunction of the product; which will also void the warranty.
  - Do not attempt to service/repair the product on your own, as this may expose you to potential electric shock and hazards, resulting in electrocution. This will also yoid the warranty claim.