

Hello!

MODEL: LPH-HP3 STTLISH WIRELESS HEADPHONES USER MANUAL



Dear Customer

Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.

Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.

Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.

If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.

LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.

LinkTech's Sales Team

Link

STTLISH WIRELESS HEADPHONES






Specification

Model Name	LPH-HP3	
Wireless Verison	V5.3	
Unit Weight	210g	
Unit Size	180x85x200mm	
Working Distance Range	10m	
Battery Capacity	3.7V, 500mAh	
Charging Time	2 Hours	
Music Time	55 Hours	
Talking Time	50Hours	
Standby Time	Up to 300 Hours	
Driver Size	2 x 40mm	
Sound Power	0.5mW	
Frequence Range	2.402GHz-2.480GHz	
Charging Port	Type-C Charging Port	
Impedance	64Ohm S.P.L (at 1KHz	

Product Diagram



Charge It

- On the right earcup, carefully plug the Type-C cable into Type-C charging port. and connect the other end of the cable to either a computer USB port or to a USB-compatible car or wall charger.
- Solid red LED light will appear to indicate when the headphone is charging.
- · When charging is complete, the LED light will turn Blue.
- · Charging time is approximately 3 hours.





Turn It On/Off

- \bullet Press & hold the power button on the right side of the headphone
 - for about 3 seconds until the LED indicator light turns on.
- Press & hold the power button again for 4 seconds until the LED light turns off.

Pair & Connect With New Device

- Power on the wireless bluetooth headphone (refer to the "Turn It On" section).
- To pair the headphone with a new device, the Red and blue LED light blink to indicate it is ready to be paired with your device.
 On your Bluetooth-enabled smartphone, tablet or media player,
- navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices After a few seconds you will see Link-HP3 listed.
- Tap this-model to select it. Solid blue LED light indicate your device has successfully paired.
- With your previously paired device's Bluetooth turned on and in range,The headphone will automatically reconnect to the last Bluetooth device it was connected to.

NOTE: If the headphone is not used within 5 minutes, the eadphones will automatically turn off to save battery.



Troubleshooting

- No power
- Recharge your wireless bluetooth headphone using the Type-C cable.
- · Music is not playing over Bluetooth
- Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth. Restart the headphone to reconnect your Bluetooth device.
- · Bluetooth device will not reconnect with the headphone
- Navigate to your Bluetooth settings menu on your Bluetooth device,tap **Link-HP3** , and select

"Forget" .

 Now follow the steps to pair your device again.Or touch & hold the power button on the headphone (while powered on) to disconnect the headphones from any connected devices.

Then follow the steps to reconnect your device.





Play

- · Connect your device to the headphone via Bluetooth
- (refer to the" Pair & Connect" section)
- · Open your favorite music app and press play.
- Control the music, track & volume from your device, or control the music & volume. Short touch the Power button once to play/pause music & answer calls, short touch it twice to redial the last number called on your phone and touch & hold it to reject an incoming call.
- All audio,including music,games,videos,and notifications will be routed through the headphone.

Touch Function

- Double-press the touching area + (refer to product Diagram) to previous track.
- Double-press the touching area (refer to product Diagram) to next track.
- Press & Hold the touching area 2s + (refer to product Diagram) to turn up the volume.
- Press & Hold the touching area 2s (refer to product Diagram) to turn down the volume.
- \cdot Three-tap Power button \ref{U} to turn on /off the voice assistant

NOTE: Press gesture and touching the correct area will offer you fluently experince