

Hello!

MODEL: LPH-HP7 ANC STEREO WIRELESS HEADPHONES USER MANUAL

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.



Thank you for choosing Link Tech product. Your choice is crucial for us,which means Link Tech has added a new user. Hope that we will bring you a good expeience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Whatsapp and Bip in the process of product experience,which can help Link Tech to constantly improve product and service.

If you encounter any problems in using this product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to Link Tech. Thank you!

Link Tech Sales Team

ANC STEREO WIRELESS HEADPHONES

2




3 /

Specification

Model Name	LPH-HP7
Wireless Verison	V 5.3
ANC Reduction	28dB
Unit Weight	210g
Unit Size	200x85x190mm
Working Distance Range	10m
Battery Capacity	3.7V, 500mAh
Charging Time	2 Hours
Music Time	55 Hours (BT)
Music Time	45 Hours (BT+ANC)
Talking Time	50 Hours
Standby Time	Up to 300 Hours
Driver Size	2 x 40mm
Charging Voltage	DC 4.2-5.5V
Frequence Range	2,402GHz-2,480GHz
Charging Port	Type-C Charging Port
Impedance	320hm S.P.L (at 1 KHz)
Battery	Built-in Lithium Battery

Product Diagram



Charge It

- On the right earcup, carefully plug the Type-C cable into Type-C charging port. and connect the other end of the cable to either a computer USB port or to a USB-compatible car or wall charger.
- Solid red LED light will appear to indicate when the headphone is charging.
- · When charging is complete, the LED light will turn Blue.
- · Charging time is approximately 5 hours.



Turn It On/Off

- Press & hold the power button on the right side of the headphone for about 3 seconds until the LED indicator light turns on.
- Press & hold the power button again for 4 seconds until the LED light turns off.

Pair & Connect With New Device

- Power on the wireless bluetooth headphone
 (refer to the "Turn It On" section).
- To pair the headphone with a new device, the Red and blue LED light blink to indicate it is ready to be paired with your device.
- On your Bluetooth-enabled smartphone,tablet or media player, navigate to the Bluetooth settings menu, turn on the Bluetooth feature, and search for new devices After a few seconds you will see Link-HP7 listed.
- Tap this- modei to select it. Solid blue LED light indicate your device has successfully paired.
- With your previously paired device's Bluetooth turned on and in range, The headphone will automatically reconnect to the last Bluetooth device it was connected to.

NOTE: If the headphone is not used within 5 minutes. the eadphones will automatically turn off to save battery.



Play

- Connect your device to the headphone via Bluetooth (refer to the" Pair & Connect" section)
- · Open your favorite music app and press play.
- Control the music track & volume from your device, or control the music & volume.Press the Power button once to play/pause music & answer calls, press it twice to redial the last number called on your phone, and press & hold it to reject an incoming call.
- All audio,including music,games,videos,and notifications will be routed through the headphone.

Button Function

- Press + area (refer to product Diagram) to next track.
- · Press area (refer to product Diagram) to previous track.
- Press & Hold + area (refer to product Diagram) to turn up the volume.
- Press & Hold area (refer to product Diagram) to turn down the volume.
- Press -W- ANC buton once then the White LED light on means ANC function turn on.
- Press & Hold 3 Sec ANC buton -W- to turn on the voice assistant.

NOTE: Press gesture and touching the correct area will offer you fluently experince



Troubleshooting

- No power
- Recharge your wireless bluetooth headphone using the Type-C cable.
- Music is not playing over Bluetooth
- Make sure your Bluetooth device has A2DP profile. Check if both devices are paired and connected over Bluetooth.Restart the headphone to reconnect your Bluetooth device.
- · Bluetooth device will not reconnect with the headphone
- Navigate to your Bluetooth settings menu on your Bluetooth device, tap Link-HP7, and select "Forget".
- Now follow the steps to pair your device again. Or, press & hold the power button on the headphone (while powered on) to disconnect the headphones from any connected devices.

Then follow the steps to reconnect your device.

CE

İmalatçı Firma LINK-TECH TRADING COMPANY LIMITED FLAT 698,6IF. FOCK CHONG BUILDING 63 HOL YUEN ROAD,KINUN TONG.KOWLOON.HONG KONG TEL:3114 7567