



Hello!

**Model: LTW-S33
True Wireless Earbuds
User Manual**

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Customer

Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.

Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.

Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.

If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.

LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.

LinkTech's Sales Team

SPORT BUDS VIII



ENC | 4 Microphones
for clearer calls

S33 is a futuristic designed earbuds with a sturdy charging case and advanced features such as: 10mm Dynamic Audio Drivers, Game Mode, Sensitive Microphone, Smart Touch Controls, and IPX4 water resistance for an immersive audio experience with a modern touch.

Indicator light

Touch area




Sound unit

Charging contact

Mic

Indicator light



User's Manual

We recommend using the cable that was included in the package to charge the earphones.

Contents List



TWS Earbuds
(2 PCS)



User's Manual
/Warranty Card (1PCS)



USB-A to USB Type-C
Charging Cable (1PCS)



Charging Case
(1 PCS)

Product Characteristics and Features

- A sensitive microphone with advanced board for clearer voice capture when making phone calls
- A modern and very comfortable in-ear design with ergonomic touch control
- A robust charging case with futuristic design, 400mAh battery and USB Type-C charging port.
- Large 10mm dynamic drivers optimized to deliver a natural sound
- Smart touch controls, to control your music and calls with a tap of a finger.
- Bluetooth v5.3 Wireless Technology support, with TWS feature to connect two devices at the same time
- Game Mode Support, allows you to have lower latency for smoother experience
- IPX4 water resistance

Safe Use Information

Read the instructions carefully before use, appearance and specifications of the device may be resized and different from the image in this manual without prior notice.


- ⚠ Do not listen to music at maximum volume for long periods of time as this can damage your hearing.
- ⚠ Consult a physician regarding the use of this device with medical equipment, or consult a medical device manufacturer for this matter
- ⚠ Use only certified wall chargers.


Product Specifications


Bluetooth Chipset IC	JL6973D4
Bluetooth Version	V5.3
Bluetooth Protocol	HFP v1.7, A2DP v1.3, AVRCP v1.6, HID v1.0
BT Decoding Mode	24bit SBC, AAC
Transmission Distance	Approximately 15m
Frequency Response	20Hz ~ 20KHz
Sensitivity	100.5dB ±2dB
Microphone Response	100Hz ~ 10KHz
Microphone SNR	~ 59dB
Audio Drivers	Ø10mm Dynamic 3mW
Impedance	32Ω
Earbuds Playing Time	Up to 7.0 Hours at 50% volume
Earbuds Talking Time	Up to 2.3 Hours at 50% volume
Standby Time	About 40 Hours
Charging Port	USB Type-C
Charging Input	DC 5V / 0.5A
Charging Time	~ 1 Hours
Earbuds Charging time	~ 30 Minutes
Battery Type	Li-ion Polymer
Charging Case's Battery	3.7V / 300mAh
Earbuds' Battery	2X 40mAh
No of Charging Time	2 ~ 3 times
Weight	4.5g Earbud / 44g Charging Case / 53g TOTAL
Water Resistance Level	IPX4

Do not do the following with the device and battery

- Do not disassemble it on your own
- Do not repair it on your own
- Do not try to modify it
- Do not overheat the battery
- Do not expose it to direct sunlight
- DO not immerse it in water
- Keep it away from sources of fire or open flame
- Do not expose this product to very low or very high temperatures, below 0°C or above 45°C
- Contact an authorized service technician.

 Do not use this product during a thunderstorm, there is a risk of electric shock or device malfunction.

 The metal contacts of the headphones and charging case must be free of dirt and not covered by foreign objects.

 Do not use this device in places with strong exposure to an electromagnetic field, this can lead to incorrect operation or damage the device.

Quick Start Guide

1. Before using the device, remove the earbuds from the case and remove the protective film from the charging contacts of the earbuds.
2. Fully charge the case along with the headphones, use the supplied cable (power adapter is not included).
3. This case has a Notification LED to indicate the charging status as follows:
 - Flashing Red Light = the case is recharging
 - Solid Red Light = the case is fully charged
 - Solid Blue Light = the case is recharging the earbuds; the Blue Light will turn off when the earbuds are fully charged.
4. Each earbud has a 2 Notification LED to indicate the charging status as follows:
 - 2 LEDs flashes Blue Light once = Low Battery
 - 1 LED that always shines Blue Light = the earbud is recharging

Power On

- Simple open the lid of charging case (When earbuds are inside). The earbuds will power on automatically, the earbud will output a "Power On" sound prompt.
- If the earbud is outside the charging case, press and hold the earbud's touch control for 2 seconds to power on manually.

Power Off

- Remove both earbuds from your ears, and place them back into the charging case in the correct orientation then close the lid.
- Earbuds will automatically switch off (and enter into charging mode).
- Earbuds will automatically power off if they're not connected to any device for more than 5 minutes
- If the earbud is outside the charging case, press and hold the earbud's touch control for 6 seconds to power on manually, the earbud will output a "Power Off" sound prompt.

To Pair with Phone and Devices

When earbuds are powered on, it will automatically enter pairing mode, the notification LEDs will flash Blue Light quickly, a sound prompt "Pairing" will be heard.

- Open Bluetooth on your device and search for "Link-S33" in the list of available devices.
- Select "Link-S33" from the list.
- S33 Earbuds are now paired with your device and ready to use, the notification LED of both earbuds will be light off once connected, a sound prompt "Connected" will be heard.

Note: These earbuds will automatically connect to the last paired device as soon as you open the lid of the charging case.

Earbuds Touch Controls

Play / Pause	Tap either earbuds twice	1x Tap Left / Right
Previous Track	Tap the left earbud thrice	2x Tap Left
Next Track	Tap the right earbud thrice	2x Tap Right
Volume Down	Tap the left earbud once	Long Press Left
Volume Up	Tap the right earbud once	Long Press Right
Answer / End Call	In phone call, Tap either earbuds twice	1x Tap Left / Right
Reject Call	When ringing, Touch and hold either earbuds for 2 seconds	2 Sec Hold Left / Right
Game Mode	When ringing, Touch and hold either earbuds for 2 seconds	2 Sec Hold Right
Voice Wakeup / Off	Touch and hold the right earbuds for 2 seconds	2 Sec Hold Left

To Reset Earbuds

- Make sure your earbuds are fully charged.
- Take out the earbuds from charging case, make sure to they're not connected
- Tap either earbud 3 times.
- The notification LED of earbuds will flash quickly and power off.
- Place the buds inside the charging case and repeat the pairing process.

Before that, remove S33 from the list of paired Bluetooth devices on your phone



link&ip Firma
LINK-TECH TRADING COMPANY LIMITED
FLAT 699A, 6/F, FOOK CHONG BUILDING 83 HOL YUEN
ROAD, KWUN TONG, KOWLOON, HONG KONG
TEL: 3114 7567