



# Hello!

**Model: LBS-M404**

**TWS Wireless Karaoke Speaker  
User Manual**

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

**Dear Customer**

**Thank you for choosing LinkTech's products, we appreciate your choice to purchase this product and we're hoping that you'll have a great time using our product.**

**Please share your experience with our products through LinkTech's customer services center either by phone, Whatsapp or Bip.**

**Feel free to express your opinions or tell us your suggestions on our channels. LinkTech will happily review all your invaluable feedback in order to improve our products and services.**

**If you encounter any problem or have difficulties with this product, please refer to the User's Manual, you can contact our customer services if you have any further questions.**

**LinkTech considers your priceless recognition and support as an encouragement to stay focused on providing high quality products and a motivation to move forward, improve our services and expand our workspace in the future.**

**LinkTech's Sales Team**

# WIRELESS KARAOKE SPEAKER



## Features

1. Large magnetic coils with delicate diaphragm for a shocking low-frequency bass, and a perfect medium to high-frequency presentation.
2. Advanced chip with MP3 decoding capability, supporting reading MP3 files from up to 32GB USB flash drive
3. FM Radio reception: high-quality digital radio with automatic channel search and storage of up to 30 channels.
4. 3.5mm AUX audio input for connection capability to a wide range of sound devices.
5. Built-in high-capacity battery for consecutive playback of up to 2 hours.
6. 6.35mm microphone input with adjustable Reverberation, Voice and Karaoke functions to offer outstanding singing and party experience.
7. Built-in battery's recharging protection for a stable and longer service life.
8. Indicator for low battery and fully charged statues.
9. Comes with belt/handle allow it to be carried more easily.
10. Support Bluetooth v5.0 features and TWS function which allows to match two speaker simultaneously for a true stereo effect.


## Specification

Model	LBS-M404
Output Power	50W
Speaker	5 inch x2
Disortion	≤1%
S/N Ratio	80dB
Battery	7.4V 5400mAh
Frequency response	40HZ-20KHZ
Product Size	136x423x195mm
AUX Mode	3.5mm AudioJack
TF Card Mode	Max 32G TF card
USB Mode	Max 32G USB-A
Charging Method	USB Type-C 5V/3A

## The bluetooth pairing operation and related parameters

1. Power: Switch on power to enter the mode of Bluetooth.
2. Switch on the Bluetooth function of Mobile phone and searching , while the Mobile phone shows "Link-M404", click the connect directly . mobile phone connection do not need password , if need password , please input"0000" to go on pairing . After success pairing , the speaker will send out a voice of prompt . it is success pairing between mobile phone and Bluetooth speaker.
3. Play the music of your mobile bphone directly and will give out beautiful voice from speaker.

## Functional Operations and Features



- 1. Power:** Long press to switch ON/OFF.
- 2. MODE/TWS:** Short press it to toggle between USB/AUX/Bluetooth/FM receiving modes. TWS interconnection mode: open the two machines that need interconnection at the same time, and switch to bluetooth mode at the same time, Pair one of them with the mobile phone's bluetooth to play music. Long press the TWS button on the machines to connect with another machines. After successful connection, synchronous music will be played. Long press the TWS button on the machines to exit the interconnection mode.
- 3.** In each mode, short press the " $<$ " key to reduce the volume.
- 4.** In each mode, short press the " $>$ " key to increase volume.

## Functional Operations and Features

- 5. ⏪ :** In the play status of USB/Bluetooth, short press it to select the previous channel. In FM receiving status, short press it to select the previous channel after a full station search has been executed.
- 6. >|| /SCAN:** In USB/Bluetooth reading status, short press it to play/pause. In FM receiving status, long press it to execute a full search (it is recommended to execute at least one full search before using radio receiving function. All founded stations will be saved even in power-off). In AUX input / FM radio status, short press it to toggle between mute and normal volume.
- 7. >>| :** In the play status of USB/Bluetooth, short press it to go to the next song. In FM receiving status, short press it to select the next channel after a full station search has been executed.
- 8. MENU:** By default the master volume adjustment, In the "MENU" mode, short press once for bass adjustment mode, short press twice for treble adjustment mode, short press three times for microphone volume adjustment mode, and short press four times for microphone reverb adjustment mode, adjust each time for 4 seconds without operation automatically jump back to the master volume adjustment, in each mode, adjust the "<" or ">" keys to control the volume output.
- 9. ☀ :** Short press it is light mode button.
- 10. EQ:** In USB/AUX/Bluetooth/FM reading status, Short press it to select an environment mode (from NOR, POP,ROC,JAZ,CLA,CUT).
- 11. Bluetooth working indicator.**

## Functional Operations and Features

12. **USB working indicator.**
13. **AUX working indicator.**
14. **Microphone working indicator.**
15. **DC 5V recharging:** DC 5V recharging port.
16. **Recharging indicator light:** When recharger is connected, the red light turns on. When the device is fully recharged, the light turns off.
17. **USB Port:** Read audio files in MP3 format in USB storage device in capacity up to 32G (FAT32).
18. **AUX IN:** External sound source input port (plug-and-play).
19. **Microphone input:** Microphone input jack.

Please Be sure to charge while music distorted.



Imalatçı Firma  
LINK-TECH TRADING COMPANY LIMITED  
FLAT 609A, 6/F, FOOK CHONG BUILDING 63 HOL YUEN  
ROAD, KWUN TONG, KOWLOON, HONG KONG  
TEL: 3114 7567