



**LBS-Q219**  
**ALARM CLOCK PORTABLE**  
**WIRELESS SPEAKER**  
**USER MANUAL**

Hello!

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Link Tech User,

Thank you for choosing Link Tech product. Your choice is crucial for us, which means Link Tech has added a new user. Hope that we will bring you a good experience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Whatsapp and Bp in the process of product experience, which can help Link Tech to constantly improve product and service.

If you encounter any problems in using this product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to Link Tech. Thank you!

Link Tech Sales Team

# ALARM CLOCK PORTABLE WIRELESS SPEAKER



## Specifications

Wireless	V5.0
Support	L2CAP/A2DP/AVCTP, can receive AUDIO signal and control the AUDIO device. Support HSP/HFP(Handsfree profile), with HANDS-FREE functions.
Working distance	10M
SNR	≥90db
Battery	3.7V about 1200mAh
Normal volume playing time	3 hours
Speaker driver	φ52mm*2
Power	4Ω/5W *2
Frequency response	120Hz-20KHz
Unit size	172x54x75mm
Unit weight	476G (not include accessories)
Charging	5V/500mA
Charging time	3-4H

## Product Feature

1. International advanced wireless chip and circuit design techniques, support all wireless devices.
2. With FM function, can search radio station broadcast automatically
3. With Hi-Fi speaker, to make sure the clear and bright sound.
4. Support Micro SD card and USB card, play MP3 format audio.
5. The wireless working distance is 10 meters.

6. With AUX line in, can directly connect the outside devices, for example, tablet PC/TV/cell phones
7. it will close automatically after 30 mins if disconnect Wireless
8. Support TWS
9. Support ALARM CLOCK , TIME CLOCK
10. Support Temperature display

## Key And Slot Function

1. USB slot: It can decode and play MP3 format audio when put the USB card into the slot.
2. TF slot: It can decode and play MP3 format audio when put TF card into the slot.
3. DC 5V slot: Use the standard Micro USB VB charging cable for power charging.
4. AUX line in slot: Use the Mini 3.5 head input through outside devices.
5. ON/OFF is Power switch



6. Short press to switch model(USB card/TF card/Wireless/line in /FM / Time CLOCK) when playing music.  
Keep the two speaker under Wireless mode without pairing ,press the "M" key for 3 seconds either of the speaker until hear a hint and meantime the button light stop flashing , now it is TWS mode ,then can pair the mobile Press twice to adjust the brightness of time display( level 2-3-0-1-2 CYCLE REPEATS), the darker brightness the longer standby time
7. When play music,(USB card/TF card/Wireless/line in), short press for "play/pause". In FM mode, press short to search station automatically, press again to stop searching. Under wireless mode with mobile paired, when call coming, press short to answer a call hands-free, press again to hand up, press twice to ring up a call..
8. When play music, Press short for last song, long press to turn down the volume.
9. When play music, press short for next song, long press to turn up the volume.

10. Alarm clock/Time set up button Press short to switch Alarm(Alarm 1 /Alarm 2/ Alarm1 &2 )

The indicator of Alarm 1 or 2on and press this button long to set up alarm clock, press short the button +/- to set up the time, press short to switch hour/minute setting . pls press Alarm clock set up button or press short any other button to exit if finishing setting , press any other button to Turn off the alarm Alarm indicator off or alarm 1& 2 both on and press this button long to set up time clock, press short the button +/-to set up the time, press short to switch hour/minute setting .

pls press Alarm clock set up button or press short any other button to exit if finishing setting

Press this button twice for alarm volume setting ( from level 1 to level 5 cycle , Default level 1

**NOTE:** In the FM mode, put in micro charging cable to get better FM radio station.

RESET button is bluit-in The hole between USB slot and TF slot :can press the button to reset the speaker