



LBS-Q213
PORTABLE
WIRELESS SPEAKER
USER MANUAL

Hello!

Please carefully read this Manual before using this Product for the very first time and well keep it for further reference.

Dear Link Tech User,

Thank you for choosing Link Tech product. Your choice is crucial for us, which means Link Tech has added a new user. Hope that we will bring you a good experience through our products and services. Also hope you will put forward the good advice and suggestions by official customer hotline, Whatsapp and Bp in the process of product experience, which can help Link Tech to constantly improve product and service.

If you encounter any problems in using this product, please refer to service process. Your support is our strongest power, also your recognition and evaluation are a great encouragement to Link Tech. Thank you!

Link Tech Sales Team

PORTABLE WIRELESS SPEAKER




Specifications

Wireless	V4.2
Support	L2CAP/A2DP /AVRCP, can receive AUDIO signal and control the AUDIO device. Support HSP/HFP(Handsfree profile), Built-in Mic for hands-free phone call
Working distance	10M
SNR	≥90db
Battery	3.7V 400mah
Normal volume playing time	1.5-3H
Speaker driver	φ52mm*1
Power	5W *1
Frequency response	120HZ-20KHZ
Unit size	73.4*73.4*102.1MM
Unit weight	271.2g
Charging	5V/500mAh

Product Feature

1. International advanced wireless chip and circuit design techniques, support all wireless devices.
2. With FM function, can search radio station broadcast automatically.
3. With Hi-Fi speaker, to make sure the clear and bright sound.
4. Support Micro SD card and USB card, play MP3 format audio.
5. The wireless working distance is 10 meters.

6. it will close automatically if disconnect Wireless for 30 mins
7. support TWS



Key And Slot Function

1. DC 5V slot: Use the standard Micro USB V8 charging cable for power charging.
2. TF slot: It can decode and play MP3 format audio when put TF card into the slot.
3. USB slot: It can decode and play MP3 format audio when put the USB card into the slot.
4. When play music, press short for last song, long press to turn down the volume.
5. When play music, press short for next song, long press to turn up the volume.

- When play music, (USB card/TF card/Wireless/line in/FM), short press to switch model. Keep the TWS speaker under Wireless mode without pairing, press the "M" key for 3 seconds either of the speaker until hear a hint "du du du" for TWS mode ,then can pair the mobile. Press the key for 3 seconds either of the speaker to close the TWS functions.
- Press long for power on /power off. When play music, (USB card /TF card/Wireless), short press for "play/pause". In FM mode, press short to search station automatically, press again to stop searching. Under Wireless mode with mobile paired, when call coming, press short to answer a call hands-free, press again to hand up, press twice to ring up a call.

NOTE: In the FM mode, put in micro charging cable to get better FM radio station.

RESET: press the button  for 8 seconds to reset the speaker